

CONNECT CABLES

Kabel anschließen | Connecter les câbles | Conectar los cables | 连接电缆

LINQ6 DEVICE

Connect Directly

Use Linq6 Extension Cable

Use Linq6 Output Adapter | Optional

D-RGB | 3-PIN JST

Phanteks D-RGB Products

FAN | 4-PIN PWM

Universal PWM Fans

OPTIONAL | LINQ6 MAINBOARD ADAPTER

LINQ6-Mainboard-Adapter | Adaptateur LINQ6 pour carte mère | Adaptador LINQ6 para placa base | LINQ6 主板适配器

Mainboard D-RGB¹ Input

OR

D-RGB Controller¹ Input4-PIN PWM Mainboard Fan Header¹ Input

PRO TIP

If the Mainboard Adapter is connected, the Mainboard input is the default.

DE

Wenn der Mainboard-Adapter angeschlossen ist, ist der Mainboard-Eingang die Standardeinstellung.

FR

Si l'adaptateur de la carte mère est connecté, l'entrée carte mère est celle par défaut.

ES

Si el adaptador de la placa base está conectado, la entrada de la placa base será la predeterminada.

CN

如果连接了主板适配器, 主板输入将作为默认设置。

IMPORTANCE NOTICE

Follow mainboard manual for instructions on D-RGB control.
befolgen Sie die Anleitung des Mainboards für die Steuerung von D-RGB.
Suivez le manuel de la carte mère pour les instructions concernant le contrôle D-RGB.
Siga el manual de la placa base para instrucciones sobre el control D-RGB.
请按照主板说明书进行D-RGB控制。

INSTALL SOFTWARE

Software installieren | Installer le logiciel | Instalar el software | 安装软件

EN Please visit our website to download the latest version of the NexLinq software.

ES Por favor, visite nuestro sitio web para descargar la última versión del software NexLinq.

DE Bitte besuchen Sie unsere Website, um die neueste Version der NexLinq-Software herunterzuladen.

CN 请访问我们的网站以下载最新版本的NexLinq软件。

FR Veuillez visiter notre site web pour télécharger la dernière version du logiciel NexLinq.

NEXLINQ SOFTWARE
www.phanteks.com/NexLinq

SAFETY INFORMATION

SICHERHEITSMITTEILUNG | INFORMATION DE SÉCURITÉ | INFORMACIÓN DE SEGURIDAD | 安全信息

In order to achieve maximum safety, we suggest that you adopt the following guidelines:

- Place the product on a clean and stable surface that allows adequate air ventilation.
- Don't use or place the product and any of its components near water, moisture, or other wet surfaces; or place the product near any heat, open flame, or other hot surfaces such as radiators, stoves, fireplaces, and candles.
- Use caution when operating the desktop PC to avoid electrical shock or damage, such as unplugging the power supply during thunderstorms, ensuring that your hands are dry before using (and handling) the desktop PC, keeping it away from any source of liquid and/or heat source, and using all other reasonable precautions needed under the circumstances.
- When connecting external devices to your desktop PC, carefully plan how the wires will be placed. Protect any connected cables from being trod on or pinched, particularly at plugs, convenience receptacles, or the point where they exit from.
- Take extra caution when handling/removing/reattaching glass components. Once removed, place the glass component on a stable surface first before proceeding.
- When unplugging any connected devices and/or cables, always pull the cable or device's plug or connector. Don't forcefully tug on its cord.
- Don't place any heavy items on top of the product.
- Make sure that the desktop PC is off, unplugged from the outlet, and that all connected devices are powered off and unplugged (if any) before installing or uninstalling any internal component to and/or from the desktop PC or product.



FR Cet appareil se recycle

REPRISE À LA LIVRAISON

OU

À DÉPOSER EN MAGASIN

OU

À DÉPOSER EN DÉCHÈTERIE

Points de collecte sur www.quefaire-demarches.fr

Privilégiez la réparation ou le don de votre appareil!

NOTE ON DISPOSAL



The WEEE symbol indicates that this product must not be disposed of with normal household waste. Through the correct disposal of this product, you will help protect the environment. For more information on the disposal of this product, please contact your local municipality, your waste disposal service or the shop where you purchased the product.

Phanteks Group Inc.

11F, No. 150, Jian 1st Rd.,
Zhonghe Dist.
New Taipei City 235

Importer EU

Axpertec Int. B.V. (EU)
20465 E Walnut Dr. N
3047 BP Rotterdam
The Netherlands

Importer US

Axpertec Inc. (US)
20465 E Walnut Dr. N
City of Industry, CA 91789
USA

THIS MANUAL IS FOR THE FOLLOWING MODELS

Dieses Handbuch gilt für die folgenden Modelle | Ce manuel concerne les modèles suivants | Este manual es para los siguientes modelos | 此手册适用于以下型号

Model Nr.

PH-NLHUB_02

Product

NexLinq Hub V2

Color

Black

LEGEND

Legende | Légende | Leyenda | 说明


Remove | Entfernen | Retirer | Eliminar | 移除

Install | Installieren | Installer | Instalar | 安装

Loosen | Lösen | Desserrer | Aflojar | 拧松


SCOPE OF DELIVERY

Lieferumfang | Contenu de la livraison | Contenido de la entrega | 交付范围

NexLinq Hub
x1Linq6 Mainboard Adapter
500 mm
x1Linq6 Output Adapter
500 mm
x1Velcro Strip
x1

NEXLINQ LAYOUT

NexLinq-Layout | Disposition NexLinq | Distribución NexLinq | NexLinq 布局



MAGNETIC MOUNTING

Magnétique bereitigung
Montage magnétique
Montage magnétique
磁性安装

VELCRO MOUNTING

Klettverschluss
Fixation Velcro
Montage con velcro
魔术粘固定

IMPORTANCE NOTICE

Follow mainboard manual for instructions.
befolgen Sie die Anleitung des Mainboards für weitere Informationen.
Veuillez suivre le manuel de la carte mère pour les instructions.
Siga el manual de la placa base para obtener instrucciones.
请按照主板说明书进行操作。

USB 2.0 HEADER

