# REVOLTCABLEKIT

#### **CABLE OVERVIEW:**



Sleeved 16-AWG motherboard cable with 3x aluminum combs

#### CPU EPS 4+4-PIN

Sleeved 16-AWG CPU cable with 2x aluminum combs

#### PCIe 6+2-PIN

Sleeved 16-AWG CPU cable with 3x aluminum combs

#### PCIe GEN5 12VHPWR


Sleeved 16-AWG GPU cable with 5x aluminum combs

#### SATA

18-AWG SATA cable 4x Sata Connectors

#### SATA | MOLEX

18-AWG SATA and Molex cable 2x Sata and 2x Molex connectors



### THIS MANUAL SUPPORTS:

PH-CBKT-CO\_BK01 PH-CBKT-CO\_WT01 PH-CBKT-G5S\_BK01 PH-CBKT-G5S\_WT01

Phanteks will not take responsibility for any damages incurred due to incorrect installation or usage of this product. This product is intended for use with the Phanteks Revolt ATX power supplies.

For an up-to-date compatibility list, check www.phanteks.com

## **CABLE QUANTITY**

Cable	PCIe GEN5 Starter Set	Complete Set
Motherboard 24-PIN	1	1
<b>CPU</b> 4+4-PIN	2	2
PCIe 6+2-PIN	0	7
PCIE GEN5 12VHPWR	1	2
SATA	2 (flat ribbon cable)	3 (sleeved)
SATA   MOLEX	2 (flat ribbon cable)	3 (sleeved)

## FOLLOW US ON SOCIAL MEDIA

(Phanteks



## SUPPORT

O YouTube Phanteks

**US & Canada** support@phanteksusa.com

Twitter

@phanteks


International support@phanteks.com






## 01 CONNECT YOUR CABLES

The cables can have a different connection on either end. Follow this overview to connect the cable to the correct port and component.




Connect the cables to the Revolt power supply:



## **02 PCIE GEN5 GPU CONNECTOR**

The PCIe Gen5 (12VHPWR) GPU connector can deliver up to 600 watts to the GPU. Make sure it is fully seated and clicked in to prevent any damage to your system.

Note that a compatible GPU is required.



### 03 CONNECT POWER CABLE

Connect the power cable to the power supply and a grounded power outlet respectively. Make sure the power supply is turned off 'O' before connecting it to a power outlet.



The Power Cable is included with the power supply.

#### 04 BESAFE!

Switch the power button to the 'I' position to turn on your system.

When making any changes to the hardware, be sure that the power button is switched from the 'I' to the 'O' position so the power supply is turned off.

